



# **Continental** HHT Update Client


Instructions to Update the  
Hand-Held Tool

(for externals)

# Download and Update Installation Instructions

## 1. Download Installation File

- › Download zip file.
- › If download of the zip-file was blocked by fire-wall / virus scanner:
  - › Download the “alternate zip file”.
  - › After successful download, change (rename) extension of the downloaded file from .zi1 to .zip
- › Unzip the file “HHT-update-client\_\_yyyy-mm-dd.zip”
- › Use “conti” as password for unzipping if necessary.
- › At the end there should be the folder “HHT-update-client\_\_yyyy-mm-dd” on your computer with the following content:



## 2. Installation


- › Ensure you have admin rights on your computer, before starting the installation process.
- › Install the drivers: Press right mouse click on the file „driver.exe“, to “Run as administrator”.
- › Do not connect the HHT during the installation.
- › Afterwards, install „Setup\_HHT-update-client.exe“

### 3. Update Process

- › Start „Continental HHT update“ from Windows Start menu.
- › If the Hand-Held Tool Update Client shows “No internet connection ...”, check the proxy settings.
- › In case of using an VPN-connection or working in a company network the correct proxy settings might be required.
- › Connect Hand-Held Tool and navigate to main menu on the HHT
- › Click on “HHT Status” on the Hand-Held Tool Update Client.
- › Follow the instructions shown on the Hand-Held Tool Update Client.

### 4. Problems with Memory Card

- › If problems on memory card are detected, click on “Close symbol” or “Continue without scanning” to avoid any interruptions to the software update tool.



## 5. Troubleshooting

- › The client can hang due to the following reasons:
  - › Application is run without drivers being installed.
  - › Defective USB cable
  - › Unstable USB connection due to some software issues on the computer.
  
- › Resolve the problem:
  - › The user should close the application and restart it again.
  - › Try a different USB port.
  - › If the behavior is still the same, install USB drivers which are provided along with the installation files of the HHT Update Client.

Continental Reifen Deutschland GmbH

Büttnerstraße 25

30165 Hannover

Germany

[www.continental-truck-tires.com](http://www.continental-truck-tires.com)

[www.continental-corporation.com](http://www.continental-corporation.com)

**Continental**   
The Future in Motion